


LONER General Purpose and SMD Soldering Tips

1. Hollow Heater Soldering Tools and Stations


Part No.	Description
920	LONER Soldering Station with CL1180 Soldering Tool and IP329 Base
925	LONER Soldering Station with CL1180 Soldering Tool and PS536 Power Supply
930	LONER Soldering Station with CL1080 Soldering Tool and IP329 Base
935	LONER Soldering Station with CL1080 Soldering Tool and PS536 Power Supply
951	LONER Soldering Station
951DX*	LONER Deluxe Soldering Station
951SX	LONER Soldering Station
952	LONER Dual Soldering Station
952DX*	LONER Dual Deluxe Soldering Station
952HX*	LONER Dual High Performance and Standard Soldering Station
952SX	LONER Dual Soldering Station
981*	LONER Digital Soldering Station
CL1080	LONER Temperature Controlled Soldering Tool (For 930 and 935 Stations)
CL1180	LONER Temperature Controlled Soldering Tool (For 920 and 925 Stations)
CL1484	LONER Constant Temperature Soldering Tool
LST11	LONER Soldering Tool (For 900 and 902 Stations)

*International Series available



2. Hollow Threaded Heater Soldering Tools and Stations


Part No.	Description
951A	LONER Soldering Station
952A	LONER Dual Soldering Station
CL1481	LONER Constant Temperature Soldering Tool
LST10	LONER Soldering Tool (For 900-10 and 902-10 Stations)



3. HP Front Loading Hollow Heater Soldering Tools and Stations

Part No.	Description
971*	LONER High Performance Temperature Controlled Soldering Station
971DX*	LONER Deluxe High Performance Temperature Controlled Soldering Station
971FX	LONER Soldering Station with Fume Extraction System
972	LONER High Performance Dual Temperature Controlled Soldering Station
972DX	LONER Deluxe High Performance Dual Temperature Controlled Soldering Station

*International Series available



(NOTE: Loosen collar when changing tips. DO NOT remove sleeve.)