

選擇開關

				Ø 22 型		Ø 25 型					
接點排列表											
接點 安裝位置	手柄位置			接點構成	L R	保持式	L R	自動復歸 (從左到右)	L R	自動復歸 (從右到左)	
	L	R			↙ ↘		↙ ↘		↙ ↘		
90° 2-位置	①	●		10	ASW210	ASS210N	ASW2110	ASS2110N	ASW2210	ASS2210N	
	②		●		ASW211	ASS211N	ASW2111	ASS2111N	ASW2211	ASS2211N	
	①	●		20	ASW220	ASS220N	ASW2120	ASS2122N	ASW2220	ASS2220N	
	②		●		ASW222	ASS222N	ASW2122	ASS2120N	ASW2222	ASS2222N	
	①	●		22	ASW222	ASS222N	ASW2122	ASS2120N	ASW2222	ASS2222N	
	②		●		ASW222	ASS222N	ASW2122	ASS2120N	ASW2222	ASS2222N	
	③	●		2R	-	ASS22RN-118	-	ASS212RB-118	-	ASS222RN-169	
	④		●		ASW222	ASS222N	ASW2122	ASS2120N	ASW2222	ASS2222N	
	①	●		2R	-	ASS22RN-119	-	ASS212RN-119	-	ASS222RN-168	
	②		●		ASW222	ASS222N	ASW2122	ASS2120N	ASW2222	ASS2222N	
45° 3-位置	①	●		20	ASW320	ASS320N	ASW3120	ASS3120N	ASW3220	ASS3220N	
	②		●		ASW302	ASS302N	ASW3102	ASS3102N	ASW3202	ASS3202N	
	①	●		22	ASW322	ASS322M	ASW3122	ASS3122N	ASW3222	ASS3222N	
	②		●		ASW322	ASS322M	ASW3122	ASS3122N	ASW3222	ASS3222N	
	③	●		40	ASW340	ASS340N	ASW3140	ASS3140N	ASW3240	ASS3240N	
	④		●		ASW340	ASS340N	ASW3140	ASS3140N	ASW3240	ASS3240N	
	①	●		04	ASW304	ASS304N	ASW3104N	ASS3104N	ASW3204	ASS3204N	
	②		●		ASW304	ASS304N	ASW3104N	ASS3104N	ASW3204	ASS3204N	
	③	●		3S	ASW33S-243	ASS33SN-243	-	-	-	-	
	④		●		ASW33S-243	ASS33SN-243	-	-	-	-	
	45° 3-位置	①	●		20	ASW3320	ASS3320N				
		②		●		ASW3302	ASS3302N				
		①	●		22	ASW3322	ASS3322N				
		②		●		ASW3322	ASS3322N				
③		●		40	ASW3340	ASS3340N					
④			●		ASW3340	ASS3340N					
①		●		04	ASW3304	ASS3304N					
②			●		ASW3304	ASS3304N					
③		●		3S	-	-					
④			●		-	-					

